SS2006/SDMPB/2024
1822

Caution: Unplug when not in use. Do not use if the cable is damaged. Keep away from heat. Do not store or use in extreme temperatures. Keep dry. Avoid contact with liquids. Risk of electric shock. Do not disassemble. Keep out of reach of children. Only use with approved chargers. Do not charge unattended. Supervise children when using this product. Do not use if the battery is damaged. Do not expose to fire or high temperatures. Do not charge in wet conditions. Do not use if the charger is damaged