
说明书
85-00NS4-1503-A.0-250414 双DTS logo
W105/H148mm 80g书写纸 冷灰印刷 136p 胶装 33国语言 NS4北美&欧洲&英泰版说明书 POPS TSCA CA65 TPCH MOAH MOSH 环保专色 PANTONE cool gray 11C

封面

P1 P136 P2 P3 P4 P5 P6~P135空白不印刷



Dolby Manufactured under license from Dolby Laboratories. Dolby, Dolby Audio, and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.

IC Statement:
This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).
Operation is subject to the following two conditions:
1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.
L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :
1. L'appareil ne doit pas produire de brouillage
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body.
Cet équipement est conforme aux limites d'exposition aux rayonnements de la IC établies pour un environnement non contrôlé. Cet équipement doit être installé et fonctionner à au moins 20 cm de distance d un radiateur ou de votre corps.
This Class B digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada. conjunction with any other antenna or transmitter.

HDMI The terms HDMI and HDMI High Definition Multimedia Interface, and the HDMI logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.

The Bluetooth word mark and logos are registered trademarks of the Bluetooth SIG and any use of such marks by Beijing Xiaomi Electronics Co., Ltd. is under license. Other trademarks and trade names are the property of their respective owners.

dts virtual:X dts FOR DTS PATENTS, SEE HTTP://WWW.DTS.COM/DTS-PATENTS/. MANUFACTURED UNDER LICENSE FROM DTS, INC. AND ITS AFFILIATES. DTS, THE DTS LOGO, DTS:X, SURROUND, VIRTUAL:X, AND THE DTS VIRTUAL:X LOGO ARE REGISTERED TRADEMARKS OR TRADEMARKS OF DTS, INC. AND ITS AFFILIATES IN THE UNITED STATES AND/OR OTHER COUNTRIES. © DTS, INC. AND ITS AFFILIATES. ALL RIGHTS RESERVED.

This equipment is a Class II or double insulated electrical appliance. It has been designed in such a way that it does not require a safety connection to electrical earth.

The lightning flash with arrowhead symbol, within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and servicing instructions in the literature accompanying the appliance.

Beijing Xiaomi Electronics Co., Ltd.
Room 802, Floor 8, Building 5, No.15 Kechuang 10th Road, Beijing Economic and Technological Development Zone, Beijing City, China.
Email: contact@support.mi.com

Manufacturer's Authorized EU Representative
Name: Xiaomi Technology Netherlands B.V.
Address: Prinses Beatrixlaan 582, 2595BM, The Hague, The Netherlands.
Email: contact@support.mi.com

Scatola	Manuale	Noto	Borsa
PAP 20	PAP 22	PAP 20	CPE 7
Carta	Carta	Carta	Plastica

RACCOLTA DIFFERENZIATA

Verifica le disposizioni del tuo Comune.
Separa le componenti e conferiscile in modo corretto.

85-00NS4-1503

说明书物料号

封底

Accessory List



Power cord x 2 HDMI cable x 1 Remote control x 1 Bracket x 2

Soundbar and TV Installation

1. Connect to the TV

Take out the HDMI cable from the accessories, and connect one end of the cable to the Soundbar and the other end to the HDMI ARC port of the TV. Depending on the audio output method of your TV, you can also use a coaxial cable or optical fiber for connection. In this case, you need to set the Soundbar to the corresponding audio input mode.
Take connecting a Xiaomi Soundbar to a Xiaomi TV as an example: First use the HDMI cable to connect the Soundbar and the TV. Go to Settings > Display & Sound > Audio output on the TV, and select the HDMI output mode. Then, turn on the Soundbar and switch the mode to HDMI input mode.

2. Connect the power supply


Soundbar: Connect the AC cable to the "AC in" port of Xiaomi Soundbar, and then connect the power plug to the socket.
woofer：将 AC 电缆入口盖连接 AC in 接口，再将电源线连接一根接入插座。

3. Turn on the Soundbar


Press the power button ⏻ on the Soundbar or press ⏻ on the remote control. The front screen will display "HI" and then display the corresponding channel mode. For the first time you use the Soundbar, it will enter HDMI mode by default.

4. 当woofer电源开关开机，并机后会与soundbar自动配对和连接，在某些情况下，您可能需要手动重新配对，重新进入配对模式步骤如下：
• 长按woofer配对键 约2S，进入和soundbar配对模式；
• 同时长按Soundbar上蓝牙键 ᛒ 和音量键 — 进入和woofer组队模式，配对中Soundbar屏幕幕会显示"Sub PAIRING"，配对成功后Soundbar屏幕滚动显示"Sub CONNECTED"。

Note: For the best sound quality experience when using the Soundbar, do not place it on the ground. If the TV does not produce sound when the Soundbar is not used, go to Settings > Display & Sound > Audio output on the TV and select an appropriate output mode.



Button Description



To reset factory settings, press and hold ⏻ and ᛒ for 3s. Then, the Soundbar will restart.
woofer恢复出厂设置：长按 ⏻ 10s，恢复出厂设置，清除woofer和RDS4 Soundbar绑定配对记录后，重启进入配对模式。

Connection to a Mobile Device

When the Soundbar is on, press the input source button ⮌ to switch to Bluetooth mode. Then, the Soundbar enters the pairing/reconnection mode, and "bT" blinks on the front screen. If there is a pairing record, the Soundbar automatically reconnects to the last disconnected device. After successful connection, the screen displays "bT" steadily.

Press the Bluetooth button ᛒ on the Soundbar or press ᛒ on the remote control to enter the Bluetooth pairing status or disconnect all currently connected Bluetooth devices and enter the Bluetooth pairing status. Open the Bluetooth settings on your phone, search for Bluetooth name "Xiaomi Soundbar Pro 21", and tap this name to initiate the connection. After the connection is successful, the screen displays "bT" steadily.

Description of different modes on the screen:
HDMI: HDMI input mode
bT: Bluetooth input mode
COA: coaxial input mode
OPT: optical fiber input mode



NFC


In Bluetooth channel mode, turn on the NFC function on your phone, keep the phone unlocked, use the NFC area of the phone to touch the NFC icon on the Soundbar, and confirm the connection on your phone. Then, the audio on the phone can be played through the Soundbar.



Wall-mounted Installation

1. Determine the hole positions


2. Drill holes according to the determined hole positions on the wall



3. Fix the Soundbar

Insert the expansion plugs into the two holes on the wall, thread the screws through the wall-mounted brackets into the expansion plugs, tighten the screws, and secure the Soundbar to the screws.

Remote Control Description



Basic Specifications

Model: MI12-4I-0B
Bluetooth: 5.3
Bluetooth frequency range: 2400MHz~2483.5MHz
Operating Temperature: 0°C to 40°C

SOUNDBAR
Dimensions: 880 x 87 x 65mm
Rated impedance: 6ohm
Rated power: 60W（30W x 2）
Transmit power: < 15dBm
Input: 100-240V~ 50/60Hz
Frequency response range: 150Hz to 20KHz（-10dB）

WOOFER
尺寸：163 x 249 x 249mm
Rated impedance: 5ohm
Rated power: 90W
Transmit power: < 15dBm
Input: 100-240V~ 50/60Hz
Frequency response range: 40Hz to 150Hz（-10dB）

Important Notes

Before using this product, please read and observe the following precautions to avoid danger.
1.The power plug is used as a device to disconnect the power supply.
2. The power outlet should be installed near the equipment and should be easily accessible. For pluggable devices, the output socket should be easily accessible.
3. When the equipment is not in use, disconnect the power supply from the equipment and remove the power plug from the power outlet.
4. To reduce the risk of electric shock, do not disassemble this product.
5. Please keep the device away from water. If foreign objects or liquids enter the device, please stop using it immediately and unplug the power plug.
6. Do not place the equipment in an unstable position. The equipment may tip over and cause personal injury.
7. For Class II apparatus only: This symbol means the equipment is a Class II or double-insulated electrical appliance.
8. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

WARRANTY NOTICE

THIS LEGAL WARRANTY NOTICE INFORMS YOU ABOUT YOUR RIGHTS UNDER THE LEGAL WARRANTY. FOR A FULL UNDERSTANDING OF YOUR RIGHTS YOU ARE INVITED TO CONSULT THE LAWS OF YOUR COUNTRY, PROVINCE OR STATE.

The duration and conditions related to the legal warranties are provided by respective local laws. For more information about the consumer warranty benefits, please refer to Xiaomi's official website https://www.mi.com/global/support/warranty. If you have purchased the Product directly from Xiaomi, in all other cases, please consult your seller. There is no guarantee that the operation of the Product will be uninterrupted or error free. Damages arising from non-compliance with the instructions related to the use of the Product are excluded. If a hardware defect is found within the Warranty period, the Product will be either (1) repaired, (2) replaced, or (3) refunded, depending on your rights under local laws. Normal wear and tear, force majeure, abuse or damage caused by the user's negligence or by a third party are excluded from the warranty. After-sales service may be any person in Xiaomi's authorized service network, Xiaomi's authorized distributors or the final vendor who sold the Products to you.
The present warranty does not apply in Hong Kong and Taiwan.
Products which were not duly imported and/or were not duly manufactured by Xiaomi and/or were not duly acquired from Xiaomi or a Xiaomi's official seller are not covered by the present warranties. As per applicable law you may benefit from warranties from the non-official retailer who sold the Product. Therefore, Xiaomi invites you to contact the retailer from whom you purchased the Product.

Notes

Simplified EU Declaration of Conformity
Hereby, Beijing Xiaomi Electronics Co., Ltd declares that the radio equipment type "Xiaomi Soundbar Pro 21 chi" is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: http://www.mi.com/global/service/support/declaration.html

RF Frequency and power
This device offers the following frequency bands in EU areas only and maximum radio-frequency power
Bluetooth 5.3

For the purpose of recycling to facilitate effective utilization of resources.
Please return this product to a nearby authorized Collection Centre registered Dismantler or Recycler,or Xiaomi Service Centre when disposing of this product.
What the Wheelie Bin symbol means:The symbol says don't dispose your e-waste into the municipal waste collection bins.That's because these wastes are hazardous in nature and need to be recycled in a special way.

Power consumption standby mode < 0.5W
Time to enter the standby mode in condition for 15 minutes

BT ON
Press the power button briefly to turn on the device. Then press the mode switch button to enter the Bluetooth mode. Finally, click the Bluetooth button to start Bluetooth pairing.

BT OFF
Click the Bluetooth button to disconnect Bluetooth. Switching to other modes will also disconnect Bluetooth. If there is no operation for 15 minutes after connecting Bluetooth, the device will automatically turn off and Bluetooth will be disabled.